

TAVOLA APPLICAZIONE LUBRIFICANTI 2019-2020

MODELLO TRATTORE	CV	MOTORE	OLIO MOTORE PREMIUM	L	OLIO MOTORE	L	ANTIGELO	L	TRASMISSIONE	L	SISTEMA IDRAULICO	L	RIDUTTORE	L	L ANTERIORE	L POSTERIORE	ASSALE ANTERIORE 4RM	L	FRIZIONE E FRENI	L	PTO ANTERIORE	L	GRASSO		
EGO																									
EGO 35	39	Tier 3			SDF SPECIAL MOTOR OIL	5,7		9									SDF UTTO	4,8					SDF GREASE EP2		
EGO 45	43	Tier 3			SDF SPECIAL MOTOR OIL	5,7	SDF GREEN TECH	9	SDF UTTO	21							SDF UTTO	4,8					SDF GREASE EP2		
EGO 55	51	Tier 3			SDF SPECIAL MOTOR OIL	5,7		9		21								4,8							
CRONO																									
CRONO 70	65	Tier4i		8,5	SDF SPECIAL MOTOR OIL	8,5		12		35,5					0,6 X 2		SDF UTTO	5			1			SDF GREASE EP2	
CRONO 80	75	Tier4i	PERFORMANCE ENGINE OIL	8,5	SDF SPECIAL MOTOR OIL	8,5	SDF GREEN TECH	12	SDF UTTO	35,5					0,6 X 2		SDF UTTO	5	SDF BRAKE OIL		1			SDF GREASE EP2	
CRONO 90	84	Tier4i		8,5	SDF SPECIAL MOTOR OIL	8,5		12		35,5					0,6 X 2			5			1			SDF GREASE EP2	
CRONO 100	92	Tier4i		8,5	SDF SPECIAL MOTOR OIL	8,5		12		35,5					0,6 X 2			5			1			SDF GREASE EP2	
STRIKE TB																									
STRIKE TB 105	97	Tier4i	PERFORMANCE ENGINE OIL	12	SDF SPECIAL MOTOR OIL	12	SDF GREEN TECH	15,5	SDF UTTO	48					1,5 X 2		SDF UTTO	8,5	SDF BRAKE OIL		1			SDF GREASE EP2	
STRIKE TB 115	107	Tier4i		12	SDF SPECIAL MOTOR OIL	12		15,5		48					1,5 X 2			8,5			1			SDF GREASE EP2	
SPARK 120-140																									
SPARK 120	110	Tier4F	PERFORMANCE ENGINE OIL	12	SDF SPECIAL MOTOR OIL	12		15,5	SDF UTTO	50					1,5 X 2			6,5						SDF GREASE EP2	
SPARK 130	121	Tier4F		12	SDF SPECIAL MOTOR OIL	12	SDF GREEN TECH	15,5		55					2,0 X 2		SDF UTTO	8,5						SDF GREASE EP2	
SPARK 140	130	Tier4F		12	SDF SPECIAL MOTOR OIL	12		15,5		55					2,0 X 2			8,5						SDF GREASE EP2	
SPARK .4																									
SPARK 155.4	149	Tier4F	PERFORMANCE ENGINE OIL	11,5		11,5		36	SDF UTTO	72				SDF UTTO (anteriore)	1,5 X 2	9 X 2	SDF UTTO	6					2,6	SDF GREASE EP2	
SPARK 165.4	166	Tier4F		11,5		11,5	SDF GREEN TECH	36	SDF UTTO	72				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6			SDF UTTO		2,6	SDF GREASE EP2	
SPARK 175.4	163	Tier4F		11,5		11,5		36		72				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK																									
SPARK 155	149	Tier4F	PERFORMANCE ENGINE OIL	15,5				36	SDF UTTO	72				SDF UTTO (anteriore)	1,5 X 2	9 X 2	SDF UTTO	6					2,6	SDF GREASE EP2	
SPARK 165	157	Tier4F		15,5				36		72				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK 175	169	Tier4F		15,5				36		72				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK 185	181	Stage V		15,5				36		72				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK 205	196	Stage V		15,5				36		72				SDF GEAR 90 LS (posteriore)	1,5 X 2	11 X 2		6					2,6	SDF GREASE EP2	
SPARK 215	201	Stage V		15,5				36		72				SDF GEAR 90 LS (posteriore)	1,5 X 2	11 X 2		6					2,6	SDF GREASE EP2	
SPARK 120-140 VRT																									
SPARK 120 VRT	110	Tier4F	PERFORMANCE ENGINE OIL	12	SDF SPECIAL MOTOR OIL	12	SDF GREEN TECH	15,5	SDF UTTO	77					1,5 X 2			6,5						SDF GREASE EP2	
SPARK 130 VRT	121	Tier4F		12	SDF SPECIAL MOTOR OIL	12		15,5		81					2,0 X 2		SDF UTTO	8,5						SDF GREASE EP2	
SPARK 140 VRT	130	Tier4F		12	SDF SPECIAL MOTOR OIL	12		15,5		81					2,0 X 2			8,5						SDF GREASE EP2	
SPARK .4 VRT																									
SPARK 155.4 VRT	149	Tier4F	PERFORMANCE ENGINE OIL	11,5				36	SDF UTTO	135				SDF UTTO (anteriore)	1,5 X 2	9 X 2	SDF UTTO	6					2,6	SDF GREASE EP2	
SPARK 165.4 VRT	157	Tier4F		11,5			SDF GREEN TECH	36	SDF UTTO	135	SDF UTTO			SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6			SDF UTTO		2,6	SDF GREASE EP2	
SPARK 175.4 VRT	163	Tier4F		11,5				36		135				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK VRT																									
SPARK 155 VRT	149	Tier4F	PERFORMANCE ENGINE OIL	15,5				36	SDF UTTO	135				SDF UTTO (anteriore)	1,5 X 2	9 X 2	SDF UTTO	6					2,6	SDF GREASE EP2	
SPARK 165 VRT	157	Tier4F		15,5				36		135				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK 175 VRT	169	Tier4F		15,5				36		135	SDF UTTO			SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK 185 VRT	176	Stage V		15,5				36		135				SDF GEAR 90 LS (posteriore)	1,5 X 2	9 X 2		6					2,6	SDF GREASE EP2	
SPARK 205 VRT	185	Stage V		15,5				36	SDF X-TREME	67				SDF GEAR 90 LS (posteriore)	1,5 X 2	12 X 2		6					2,6	SDF GREASE EP2	
SPARK 215 VRT	201	Stage V		15,5				36		67				SDF GEAR 90 LS (posteriore)	1,5 X 2	12 X 2		6					2,6	SDF GREASE EP2	
MACH VRT																									
MACH 230 VRT	220	Stage V	PERFORMANCE ENGINE OIL	17			SDF GREEN TECH	36	SDF X-TREME	85	SDF UTTO			SDF UTTO (anteriore)	0,8 X 2	9 X 2	SDF UTTO	5,8				SDF UTTO		2,6	SDF GREASE EP2
MACH 250 VRT	238	Stage V		17				36		85				SDF GEAR 90 LS (posteriore)	0,8 X 2	9 X 2		5,8					2,6	SDF GREASE EP2	
SPIRE F VRT																									
SPIRE F 90 VRT	83	Tier4i	PERFORMANCE ENGINE OIL	8,5	SDF SPECIAL ENGINE OIL	8,5		12	SDF UTTO	43					1,5 X 2		SDF UTTO	6	SDF BRAKE OIL		1			SDF GREASE EP2	
SPIRE F 90.4 VRT	84	Tier4i		12	SDF SPECIAL ENGINE OIL	12	SDF GREEN TECH	13		43					1,5 X 2			6			1			SDF GREASE EP2	
SPIRE F 100 VRT	91	Tier4i		8,5	SDF SPECIAL ENGINE OIL	8,5		12		43					1,5 X 2			6			1			SDF GREASE EP2	
SPIRE F 105 VRT	97	Tier4i		12	SDF SPECIAL ENGINE OIL	12		13		43					1,5 X 2			6			1			SDF GREASE EP2	
SPIRE F 115 VRT	107	Tier4i		12	SDF SPECIAL ENGINE OIL	12		13		43					1,5 X 2			6			1			SDF GREASE EP2	
SPIRE S VRT																									
SPIRE S 90 VRT	83	Tier4i	PERFORMANCE ENGINE OIL	8,5	SDF SPECIAL ENGINE OIL	8,5		12	SDF UTTO	35					1 X 2		SDF UTTO	6	SDF BRAKE OIL		1			SDF GREASE EP2	
SPIRE S 90.4 VRT	91	Tier4i		8,5	SDF SPECIAL ENGINE OIL	8,5	SDF GREEN TECH	12		35					1 X 2			6			1			SDF GREASE EP2	
SPIRE S 100 VRT	84	Tier4i		12	SDF SPECIAL ENGINE OIL	12		12	SDF UTTO	35					1 X 2			6			1			SDF GREASE EP2	
SPIRE S 105 VRT	97	Tier4i		12	SDF SPECIAL ENGINE OIL	12		12		35					1 X 2			6			1			SDF GREASE EP2	
SPIRE S 115 VRT	107	Tier4i		12	SDF SPECIAL ENGINE OIL	12		12		35					1 X 2			6			1			SDF GREASE EP2	
SPIRE V VRT																									
SPIRE V 90 VRT	83	Tier4i	PERFORMANCE ENGINE OIL	8,5	SDF SPECIAL ENGINE OIL	8,5		12	SDF UTTO	35					1 X 2		SDF UTTO	6	SDF BRAKE OIL		1			SDF GREASE EP2	
SPIRE V 90.4 VRT	91	Tier4i		8,5	SDF SPECIAL ENGINE OIL	8,5	SDF GREEN TECH	12		35					1 X 2			6			1			SDF GREASE EP2	
SPIRE V 100 VRT	84	Tier4i		12	SDF SPECIAL ENGINE OIL	12		12	SDF UTTO	35					1 X 2			6			1			SDF GREASE EP2	
SPIRE V 105 VRT	97	Tier4i		12	SDF SPECIAL ENGINE OIL	12		12		35					1 X 2			6			1			SDF GREASE EP2	
SPIRE V 115 VRT	107	Tier4i		12	SDF SPECIAL ENGINE OIL	12		12		35					1 X 2			6			1			SDF GREASE EP2	
STRIKE C																									
CF 90	83	Tier4i	PERFORMANCE ENGINE OIL	7,5	SDF SPECIAL MOTOR OIL	7,5		13	SDF UTTO	53						2,5 X 2					1			SDF GREASE EP2	
CF 100	91	Tier4i		7,5	SDF SPECIAL MOTOR OIL	7,5		13		53						2,5 X 2					1			SDF GREASE EP2	
CM 105	97	Tier4i		11	SDF SPECIAL MOTOR OIL	11	SDF GREEN TECH	14	SDF UTTO	53				SDF GEAR 90 LS		2,5 X 2					1			SDF GREASE EP2	
CM 115	107	Tier4i		11	SDF SPECIAL MOTOR OIL	11		14		53						2,5 X 2					1			SDF GREASE EP2	
C 115	113	Tier4i		11	SDF SPECIAL MOTOR OIL	11		14		53						2,5 X 2					1			SDF GREASE EP2	

SDF si riserva il diritto di apportare modifiche alle applicazioni dei lubrificanti e dei grassi senza obbligo di preavviso. Fare sempre riferimento al libretto di uso e Manutenzione per l'utilizzo e le specifiche dei lubrificanti e dei grassi.